



PURE
CASINO
EDMONTON

THE MEZZ
EQUIPMENT GUIDE



IN CASE OF EMERGENCY

**PLEASE ENSURE YOU HAVE USED
THE INCLUDED DOCUMENTS TO
TROUBLE SHOOT FIRST**

MARKETING - TEXT PREFERRED

Lacey Slater

780-699-2925

FOR MAJOR TECH ISSUES

MAY RESULT IN SERVICE CHARGE

Bill Hanson - H FACTOR PRODUCTIONS

780-991-2418

TELEVISION TO MAIN SCREEN

FOR VIDEO + SOUND

1. Ensure both hanging speakers are turned on via switch on back. DO NOT adjust volume settings on speakers.
2. Check that all cables on Shaw Box are fully plugged in to correct slots.
3. Ensure TV/Monitor is on HDMI Input
4. Use Shaw remote to put TV/Box on channel that you want (ex. Sportsnet).
5. Turn on the Main Mixer Board
6. Ensure TAPE IN is pressed.
7. Use MAIN MIX to control volume. Do not adjust volume settings on actual speakers.



LAPTOP TO MAIN SCREEN

FOR VIDEO ONLY

1. From the Shaw box, unplug the HDMI cord.
2. Plug HDMI cord into Laptop or applicable device.
3. What is on your screen will now be projected onto large screen.
 - a. If your content is not showing, check your device settings are set to duplicate your screen onto the projector.
4. When finished, ensure that following the HDMI cord is plugged back into the Shaw box.



STAGE LIGHTS

FOR THE PROGRAMMED STAGE LIGHTING

1. Use the DMX Controller used to control the stage lights.
2. Only 3 are used:
 - a. **Blackout (Off)** – Press this to turn the lights on or off
 - b. **White** – Sets all lights to white
 - c. **Colour** – Sets lights to randomly respond the room audio

Please use any of the 3 choices above. Do not set up your own.



MICROPHONE

1. Ensure both hanging speakers are turned on via switch on back. **DO NOT** adjust volume settings on speakers.
2. Plug Microphone into sound board under **MIC 1 AUX INPUT**
6. Ensure **TAPE IN** is turned off (otherwise it will project TV sound).
7. Use **MAIN MIX & MIC LEVEL** to control volume. Do not adjust volume settings on actual speakers.



Extra Cables, Wipes, Electronic Wipes and the Microphone can be found in the black basket in The Mezz.

Please maintain and keep all items organized.

Should The Mezz require additional cleaning (ex. floors, tables, etc.) please alert maintenance.

