



THE SOCIAL EQUIPMENT SET UP

**IN EMERGENCY
PLEASE CALL OR TEXT**

**H FACTOR PRODUCTIONS
BILL HANSON
780-991-2418**

NOTE: There is a charge to have them come troubleshoot.





USB

Control

Audio Network

AES Out

STUDIO LIVE 32SC

PreSonus

Power

100-230V~, 50-60 Hz, 65W

Mono Sum

Talkback +48

Mic 8

Mic 7

Mic 6

Mic 5

Mic 4

Mic 3

Mic 2

Mic 1

Level

Level

Main Output

Right

Left

Mic/Line 16

Mic/Line 15

Mic/Line 14

Mic/Line 13

Mic/Line 12

Mic/Line 11

Mic/Line 10

Mic/Line 9

Tape

In

Out

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

L

R

Mix 7

Mix 6

Mix 5

Mix 4

Mix 3

Mix 2

Mix 1

Mix 10

Mix 8

Mix 7

Mix 6

Mix 5

Mix 4

Mix 3

Mix 2

Mix 1

CAUTION

WARNING: To prevent the risk of fire or electric shock, do not connect the power cord to a power outlet until the mixer is properly grounded. Do not connect the power cord to a power outlet until the mixer is properly grounded. Do not connect the power cord to a power outlet until the mixer is properly grounded.

AVISO: Antes de conectar el cable de alimentación, asegure de que el equipo esté correctamente conectado a tierra. No conecte el cable de alimentación hasta que el equipo esté correctamente conectado a tierra. No conecte el cable de alimentación hasta que el equipo esté correctamente conectado a tierra.

12203

PreSonus Audio Electronics, Inc. 4881 West 19th Street, Suite 1000, Tempe, AZ 85281-1000, USA

CE FCC



